

TEMPORARY REVISION

AMM-TR-MÄM 42-1192

Removal of Part Number of Air Filter

This Temporary Revision AMM-TR-MÄM 42-1192 is approved in conjunction with the Mandatory Design Change Advisory MÄM 42-1192/a and is valid in conjunction with the Airplane Maintenance Manual (AMM) until this Temporary Revision has been incorporated into the AMM, latest revision.

The limitations and information contained herein either supplement or, in the case of conflict, override those in the AMM.

The technical information contained in this document has been approved under the authority of DOA No. EASA.21J.052.

Doc. No.	Section	Affected Pages
7.02.01	71-60-00	3a, 3aa

Instruction

- Print this document double-sided on yellow paper (odd pages and "a" pages on front sides, even pages and "aa" pages on reverse sides).
- Insert this cover page as the first page of the AMM.
- Insert the other pages of this Temporary Revision in front of the corresponding AMM pages.

Intentionally left blank

AFFECTED CHAPTERS:**CHAPTER 71**
POWER PLANT
Section 71-60
Air Intakes**2. Description****C. Air Filter**

The paragraph is amended to read:

Refer to Figure 1. The air filter locates on the air filter housing, on the right of the engine compartment, just forward of the firewall. It is held to the forward face of the alternate air valve by a worm drive clamp.

Intentionally left blank