

Checklist für Diamond DA40 NG

Edition #: **17.2** Edition date: **15.03.2017**

Please observe:

The file you are receiving hereby combines all three sections of the checklist: Normal Checklist, Emergency Checklist and Abnormal Checklist.

All pages of a new edition will have the same new "edition #" and "edition date", even if only one page was amended and all other pages still have the same, unchanged content.

Therefore the "List of Effective Pages" (LEP) is provided. It is here where you can see whether a particular page was amended. Pages which have been amended by a new edition will be marked **yellow**. For all other pages you will see which original "edition #" (and of course any higher "edition #") is still valid.

Note:

The system of assigning "Edition #" is as follows:

- if the revision affects all types, a new edition # (without a decimal figure) will be assigned to all of the checklists
- if the revision does not affect all types, the affected checklists will get subsequent "decimal figures" until a major revision affecting all checklists is issued.

Have a lot of nice flights and happy landings!

Peter Schmidleitner

Comments explaining Edition # 17.2 are on page 2 of this document

Checklist DA40 NG - LEP

Page	Following Edition Date (or any higher) is valid	
Section : Normal Checklist		
1	15	20.05.2010
2	17	01.03.2015
3	16.4	01.08.2014
4	17	01.03.2015
5	17.2	15.03.2017
6	16.2	01.06.2014
7	17.2	15.03.2017
8	17	01.03.2015

Section: Emergency Checklist		
1	15.2	15.12.2011
2	17.1	01.06.2016
3	15.2	15.12.2011
4	15.2	15.12.2011
5	15.2	15.12.2011
6	15.2	15.12.2011
7	15.3	15.12.2011
8	17	01.03.2015
9	15.2	15.12.2011
10	15.2	15.12.2011
11	15.2	15.12.2011
Section: Abnormal Checklist		
12	16.4	01.08.2014
13	17.1	01.06.2016
14	16.4	01.08.2014
15	16.4	01.08.2014
16	17	01.03.2015

Comments explaining Edition # 17.1

Emergency Prodedures

Page 2:

Emergency landing (Engine OFF): Fuel pumps OFF added

Abnormal Procedures

Page 13:

Editorial correction

Comments explaining Edition # 17.2

Normal Procedures

Page 5: Gearbox temperature before ECU Test

Page 7: "SECURING THE AIRCRAFT" added

Emergency Prodedures

No change

Abnormal Procedures

No Change

NORMAL CHECKLIST



This checklist is compiled according the guidelines of GAMA Specification No.1, SECTION 3, para 3.5, SECTION 3A, para 3A.5 and SECTION 4, para 4.5.

The „Amplified Normal Procedures“, „Amplified Emergency Procedures“ and „Amplified Abnormal Procedures“ according GAMA Specification No. 1 are in the DA40 Airplane Flight Manual Chapters 4A, 3 and 4B.

This checklist is a Recommended Operator Checklist and for reference only.

It is not a substitute for and does not supersede the current approved Airplane Flight Manual or any of its supplements or parts thereof, or any training or procedures required by any regulatory or advisory bodies.

This checklist may not contain all procedures shown in the Airplane Flight Manual. For a comprehensive listing of all procedures consult the Airplane Flight Manual.

Use of the checklist is at the user's sole risk and discretion.

Any possible liability of Diamond Flight Training and/or Diamond Aircraft Industries for any damages, injury or death resulting from its use is excluded.

All such terms and conditions shall be deemed to be explicitly accepted in full by using the checklist. If you do not understand, or if you disagree with, any of the above terms and conditions and in any jurisdiction that does not give effect to all provisions of these terms and conditions any use of the checklist is not permitted.

Use of the electronic checklist (if available):

Before using the electronic checklist on the G1000 the following sections have to be completed using this paper checklist:

- Preflight interior + exterior
- Preflight exterior
- Check before engine start items 1 to 21 (may be completed by heart).

This checklist also serves as a back up for the electronic checklist in case the G1000 MFD is not available.

For use of fuel additives see AFM.

PREFLIGHT INTERIOR + EXTERIOR.

- 1 Check Aircraft papers
- 2 Remove pitot cover
- 3 Check interior for foreign or loose objects
- 4 Check flight controls free
- 5 Check circuit breakers
- 6 Fuel Valve NORMAL
- 7 Engine Master OFF
- 8 VOTER switch AUTO
- 9 Fuel pumps OFF
- 10 Essential bus OFF
- 11 Avionic Master + electrics OFF
- 12 Electric Master ON
check voltage
- 13 Check fuel quantity + temp
- 14 External lights ON
- 15 Pitot heat ON
- 16 Parking brake SET
- 17 Check stall warning
- 18 Check pitot tube
- 19 Check external lights
- 20 Pitot heat / ext. lights OFF
- 21 Electric Master OFF,
key removed

PREFLIGHT EXTERIOR

Left main gear

Wheel fairing
Tire condition, slip mark
Brake, hydraulic line

Left wing

Wing leading edge, top- and bottom surface
Drain fuel tank
Air intake (winter baffle ?)
Stall warning
Fuel vent
Fuel filler cap
Pitot probe (cover removed)
Landing/Taxi light
Wing tip, position light
Static dischargers
Aileron (freedom of movement, hinges, control linkage, security)
Wing flap

Left fuselage

Canopy left side
Rear door
Fuselage left side
Antennas

Tail

Elevator & rudder (freedom of movement, hinges)
Trim - tab
Tail skid + lower fin
Static dischargers

Right fuselage

Fuselage right side
Rear window
Canopy right side

Right wing

Wing flap
Aileron (freedom of movement, hinges, control linkage, security)
Static dischargers
Wing tip, position light
Wing leading edge, top- and bottom surface
Fuel filler cap
Fuel vent
Fuel cooler air inlet (winter baffle ?)
+ outlet
Drain fuel tank

Right main gear

Wheel fairing
Tire condition, slip mark
Brake, hydraulic line

Nose section

OAT sensor
Propeller surface
Spinner
Cowling, Air inlets (7)

Nose gear

Wheel fairing
Tire condition, slip mark

Engine bay

Engine oil level (5,0 – 7,0 l)
Gearbox oil level
Drain gascolator

Chocks removed
Towbar removed

CHECK BEFORE ENGINE START

1	Preflight check	COMPLETED	1
2	Baggage and tow bar	SECURED	2
3	Fuel valve.....	NORMAL / SECURED	3
4	Power lever	IDLE	4
5	Parking brake.....	SET	5
6	Alternate Air	CLOSED	6
7	Electric master	OFF	7
8	Avionic master	OFF	8
9	Essential bus.....	OFF	9
10	Alternate static.....	CLOSED	10
11	Engine master.....	OFF	11
12	VOTER switch.....	AUTO	12
13	Fuel pumps.....	OFF	13
14	All light switches.....	OFF	14
15	Emergency switch.....	OFF / GUARDED	15
16	ELT.....	ARMED	16
17	Circuit breakers	CHECKED IN	17
18	Flap selector	UP	18
19	Pitot heat	OFF	19
20	Fuel transfer	OFF	20

If starting with external power:

External power CONNECT

21	Electric Master	ON (check avionic fan noise)	21
22	Rudder pedals	ADJUSTED	22
23	Passengers	INSTRUCTED	23
24	Seat belts.....	FASTENED	24
25	Rear door	CLOSED and LATCHED	25
26	Front canopy.....	POS 1 or 2	26
27	G1000.....	POWERED, ACKNOWLEDGED	27
28	MFD.....	EIS – FUEL	28
29	Fuel Quantity	CHECKED, RESET/SET if requ.	29
30	Fuel temperature.....	CHECKED	30
31	Total time in service.....	NOTED	31
32	MFD	EIS - SYSTEM	32
33	Power lever	IDLE	33
34	ACL (strobe).....	ON	34

End of Checklist

ENGINE START PROCEDURE

Engine Master ON
 Annunciations / Eng.Instr. CHECKED
 Glow indication OFF
 Propeller area CLEAR
 Start key..... START
 Oil pressure OUTSIDE RED within 3 sec
 Voltage, Electrical load CHECK INDICATION
 Annunciations / Eng.Instr. CHECK

CHECK AFTER ENGINE START

If external power was used:

External power DISCONNECT

1	Oil pressure.....	CHECKED	1
2	RPM 710 +/- 30	CHECKED	2
3	Circuit breakers	CHECKED IN	3
4	Pitot heat ON, annunciation + Amps checked		4
5	Pitot heat	OFF	5
6	Avionics master	ON	6

FMS SETUP

I nitialize profile (AUX 4, MAP)
F light plan
R adios (COM, NAV, ADF, DME, CDI, BRG 1/2)
P erformance (speed bugs, flight ID if applicable)

7	FMS setup.....	COMPLETED	7
---	----------------	-----------	---

AUTOPILOT TEST

DISCONN press, check electric trim not working
AP ON, check annunciations and *FD*
DISCONN press, check *AP* off
GA button press, check *FD* commands climb, *FD OFF*

8	Autopilot test.....	COMPLETED	8
9	Flood light	CHECKED, ON as required	9
10	Position lights	ON as required	10
11	Flaps	full travel CHECKED, then T/O	11
12	Altimeters (2)	SET	12
13	Standby horizon.....	CHECKED	13
14	Transponder	CODE/MODE CHECKED	14
15	Engine temperatures	CHECKED	15
16	Parking brake	RELEASED	16

Max power 50% until engine temperatures in green range

End of Checklist; see next page for "During taxi" – items

DURING TAXI

Check brakes
 Check flight instruments

BEFORE TAKE OFF CHECK

1	Parking brake	SET	1
2	Seat belts	FASTENED	2
3	Adjustable backrests.....	UPRIGHT	3
4	Rear door.....	CLOSED + LATCHED	4
5	Front canopy	CLOSED + LATCHED	5
6	Door warning light.....	OFF	6
7	Circuit breakers	CHECKED	7
8	Electric elevator trim	CHECKED, T/O SET	8
9	Flaps	CHECKED T/O	9
10	Flight controls.....	CHECKED	10
11	Power lever	IDLE	11
12	MFD	EIS – SYSTEM	12
13	Engine instruments	CHECKED	13

*Engine temperatures must be in green range before performing ECU test.
 (For gearbox min.38° recommended). For warm up max power 50%.*

14	VOTER switch	A, AUTO, B, AUTO	14
----	--------------------	------------------	----

ECU TEST

ECU test button..... *press and hold*
 "ECU A/B fail"

ON

Prop cycling 2 times > 1900 RPM
 "ECU A/B fail"

OFF

ECU test button..... *release*

15	ECU test	PERFORMED	15
16	Pitot heat	AS REQUIRED	16
17	Transponder	CODE/MODE CHECKED	17
18	Fuel pumps	ON	18
19	MFD	EIS – DEFAULT	19
20	Parking brake	RELEASED	20

End of Checklist

LINE UP PROCEDURE

Landing light..... *ON*
 Approach sector

CLEAR

Runway..... *IDENTIFIED*

Available power check (see pg.6) PERFORMED

Available Power Check:

10 sec. power MAX, RPM 2200 – 2300 (min. 2100 below -10°C), min. load acc. table below

Altitude [ft]	OAT								
	-35°C -31°F	-20°C -4°F	-10°C 14°F	0°C 32°F	10°C 50°F	20°C 68°F	30°C 86°F	40°C 104°F	50°C 122°F
0	94%						95%	92%	90%
2000	94%						95%	92%	/
4000	94%						95%	92%	/
6000	96%						95%	92%	/
8000	96%					95%	94%	91%	/
10000	96%			94%	93%	91%	88%	/	/

AFTER TAKE-OFF PROCEDURE

After passing safe altitude:

Flaps UP

Climb power SET

CLIMB TO CRUISE CHECK

1	Flaps	CHECKED UP	1
2	Fuel pumps	OFF	2
3	Climb power	SET	3
4	Landing light	OFF	4

End of Checklist

PERIODICALLY DURING CRUISE

Fuel transfer repeat as required

Maximum fuel unbalance - Long range tank: 9 USG

DESCENT / APPROACH CHECK

1	Landing data	RECEIVED	1
2	Altimeters (2)	SET	2
3	COM / NAV / FMS	SET	3
4	Seatbelts	FASTENED	4
5	Adjustable backrests.....	UPRIGHT	5
6	Fuel transfer.....	AS REQUIRED	6
7	Parking brake	CHECKED RELEASED	7
8	Fuel pumps	ON	8
9	Landing light	ON	9

End of Checklist

BEFORE LANDING PROCEDURE

Downwind, latest base leg:

Flaps T/O

On final:

Flaps LDG

GO AROUND PROCEDURE

Power MAX

Flaps T/O

Continue with take-off profile

AFTER LANDING CHECK

1	Flaps	UP	1
2	Pitot heat	OFF	2
3	Fuel pumps	OFF	3
4	Alternate air	CLOSED	4
5	Landing/Taxi light	AS REQUIRED	5

End of Checklist

PARKING CHECK

1	Parking brake	SET	1
2	Power lever	max 10% for 1 min.	2
3	ELT	CHECK not activated	3
4	Engine / System page.....	CHECKED	4
5	Engine / Fuel page	TTL TIME IN SVC NOTED	5
6	Avionic master	OFF	6
7	Electrical consumers except ACL (strobe)	OFF	7
8	Engine Master.....	OFF	8
9	ACL (strobe).....	OFF	9

When engine indications x-out red:

10	Electric Master	OFF	10
11	Start key.....	REMOVED	11

End of Checklist

SECURING THE AIRCRAFT

Release parking brake, use chocks.

Cover the pitot probe.

Attach tie down ropes to mooring points

STALLING SPEEDS KIAS				
	1000kg	1100kg	1200kg	1310kg
Stalling speed (V _S) Flaps UP	58	61	64	66
Stalling speed (V _S) Flaps T/O	54	56	60	62
Stalling speed (V _{S0}) Flaps LDG	55	57	59	60

OPERATING SPEEDS KIAS

	940kg	1000kg	1100kg	1200kg	1280kg + above
Rotation speed	56	58	61	65	67
V ₅₀ up to 50 ft	62	65	67	70	72
V _y up to safe altitude	72				
Cruise climb speed	88				

Max. cruising speed (V _{N0})	130				
Never exceed speed (V _{NE})	172				
Max. flap speed (V _{FE}) Flaps T/O	110				
Max. flap speed (V _{FE}) Flaps LDG	98				

	940kg	1000kg	1100kg	1200kg	1216kg	1280kg +above
Approach V _{REF} Flaps UP	71	73	78	82	82	83
Approach V _{REF} Flaps T/O	68	70	74	77	77	78
Approach V _{REF} Flaps LDG	66	68	72	76	76	77
Min. GA speed Flaps T/O	72					

	up to 1080 kg	1081-1180 kg	above 1080 kg
Manoeuvring speed (V _O)	101	108	113

Best gliding Flaps UP, windmilling prop	88
	Gliding ratio 1:9,7 1,59 NM / 1000 ft
	Without wheel fairings: Gliding ratio 1:9,4 1,54 NM / 1000 ft

Max demonstrated X-wind: 25 kt

MASS		
		Option "574" Option "662"
Max. TKOF mass	1280 kg	1310 kg
Max ZF mass	1200 kg	1265 kg
Max. LDG mass	1216 kg	1280 kg
Empty mass	900 kg	
Max. baggage in FWD compartment	45 kg	
Max. baggage in AFT extension	18 kg	
Total in both	45 kg	

EMERGENCY + ABNORMAL CHECKLIST

For conditions to use this Emergency + Abnormal Checklist see page 1 of the Normal Checklist.
All such conditions are fully applicable also for this checklist.

G1000 WARNINGS

ENG TEMP	Pg. 6	Coolant temperature high (red range)
OIL TEMP	Pg. 6	Oil temperature high (red range)
OIL PRES	Pg. 6	Oil pressure low (red range)
GBOX TEMP	Pg. 7	Gearbox temperature high (red range)
L/R FUEL TEMP	Pg. 7	Fuel temperature high (red range)
FUEL PRESS	Pg. 7	Fuel pressure low
ALTN AMPS	Pg. 7	High Current (red range)
ALTN FAIL	Pg. 7	Alternator failed
STARTER	Pg. 8	Starter not disengaging
DOOR OPEN	Pg. 8	Unlocked doors

For other parameters "out of green range" see Abnormal Checklist

Abnormal Checklist starts at page 12

Emergency landing (engine off) page 2

Engine

Engine failure in flight	page 2
Windmill engine start	page 3
Engine troubleshooting.....	page 4
Oscillating RPM.....	page 5
RPM overspeed	page 5
RPM underspeed	page 5

Electric System

High current	page 9
Total electrical fail	page 9

Smoke and Fire

Engine fire in flight	page 2
Electric fire / smoke in flight	page 9
Fire / smoke on ground	page 10
Fire / smoke in continued TKOF.....	page 10

Other Emergencies

Unintentional flight into icing	page 8
Landing with defective main gear tire.....	page 11
Landing with defective brakes	page 11
Fuel transfer pump u/s	page 11
Suspicion of carbon monoxide	page 11

ENGINE FAILURE IN FLIGHT

- 1 Airspeed..... 88 KIAS 1
 - 2 Flaps UP 2
- Depending on remaining altitude consider:
RESTART (page 7) or
EMERGENCY LANDING (ENGINE OFF) (see ↓)

EMERGENCY LANDING (ENGINE OFF)

- 1 Gliding speed..... 88 KIAS 1
 - 2 ATC INFORM 2
 - 3 Engine master..... OFF 3
 - 4 Adjustable backrests..... UPRIGHT 4
 - 5 Fuel transfer pump OFF 5
 - 6 Fuel pumps..... OFF 6
 - 7 Fuel valve OFF 7
 - 8 Avionic master OFF 8
 - 9 Safety harness..... TIGHT 9
- On final:
- 10 Flaps T/O or LDG 11

	Approach speed KIAS				
Flaps	1000 kg	1080 kg	1160 kg	1216 kg	1280 kg
T/O	70	73	76	77	78
LDG	69	72	74	76	77

- 11 Electric master switch OFF 10

ENGINE FIRE IN FLIGHT

- 1 Cabin heat..... OFF 1
 - 2 Canopy UNLATCH as necessary 2
- Select emergency landing area
 When certain to reach landing area:
- 3 Fuel valve OFF 3
 - 4 Power lever MAX 4
 - 5 Emergency windows OPEN as necessary 5
- Carry out:
EMERGENCY LANDING (ENGINE OFF) (see ↑)

WINDMILL ENGINE START

Do not consider starter assisted
restart if propeller has stopped

Max. altitude:

16.400 ft PA for immediate restart

10.000 ft PA for restart within 2 minutes

- | | | | |
|----|-----------------------------|----------------|----|
| 1 | Airspeed..... | 88 KIAS | 1 |
| 2 | Power lever | IDLE | 2 |
| 3 | VOTER switch | CHECKED AUTO | 3 |
| 4 | Fuel valve | CHECKED NORMAL | 4 |
| 5 | Alternate air | AS REQUIRED | 5 |
| 6 | Fuel quantity | CHECKED | 6 |
| 7 | Fuel transfer pump | AS REQUIRED | 7 |
| 8 | Electric master | CHECKED ON | 8 |
| 9 | Engine master..... | CHECKED ON | 9 |
| | ● If engine does not start: | | |
| 10 | Fuel valve | EMERGENCY | 10 |
| | ● If engine does not start: | | |
| 11 | Flaps | UP | 11 |

Carry out:

EMERGENCY LANDING (ENGINE OFF) (page 2)

ENGINE TROUBLESHOOTING

- 1 Airspeed..... 88 KIAS 1
- 2 Power lever MAX 2

❖ If

ECU A AND B FAIL
simultaneously

and ALL of the following conditions exist:

- indicated **LOAD unchanged**
- **perceived thrust is reduced**
- **engine noise level changes or engine running rough**

- 3 POWER lever IDLE for 1 second 3
- 4 POWER lever slowly increase to 1975 RPM 4
 - If engine shows power loss during the POWER lever increase
- 5 POWER lever idle for 1 second 5
- 6 POWER lever slowly increase 6
 - stop prior to the RPM where former engine power loss was observed

Do not increase the POWER lever past the propeller speed of 1975 RPM or the setting determined in step 4. An increase of engine power beyond this setting leads into another power loss.

With this power setting the engine can provide up to 65% at the maximum propeller speed of 1975 RPM

- 7 Land at nearest suitable airfield..... 7

End of Checklist

❖ Otherwise:

- 3 Circuit breakers..... CHECK/RESET 3
 - If engine OK: continue, land ASAP End of Checklist
- 4 VOTER switch SWAP between A and B 4
 - If engine OK: continue, land ASAP End of Checklist
- 5 VOTER switch AUTO 5
 - If engine OK: continue, land ASAP End of Checklist
- 6 Fuel valve EMERGENCY 6
 - If engine OK: continue, land ASAP End of Checklist
- 7 Fuel valve NORMAL 7
- 8 Alternate air OPEN 8
 - If engine OK: land as soon as practicable End of Checklist
 - If engine still not OK: be prepared for ENGINE FAILURE IN FLIGHT, land ASAP End of Checklist

OSCILLATING RPM

- | | | | |
|---|-----------------------------------|----------------------|---|
| 1 | Power lever | CHANGE SETTING | 1 |
| | ● If no success: | | |
| 2 | VOTER switch | SWAP between A and B | 2 |
| | ● If no success: | | |
| 3 | VOTER switch | AUTO | 3 |
| | Land at nearest suitable airfield | | |

RPM OVERSPEED

- | | | | |
|----|-----------------------------------|-------------------------|----|
| 1 | Power lever | ADJUST to max. 2300 RPM | 1 |
| 2 | Airspeed..... | 88 KIAS | 2 |
| 3 | Flaps | UP | 3 |
| ↕ | If RPM stabilized below 2300: | | |
| 4 | Airspeed..... | AS REQUIRED | 4 |
| 5 | Power lever | AS REQUIRED | 5 |
| | but do not exceed 2300 RPM | | |
| ↕ | If RPM still above 2300: | | |
| 6 | VOTER switch | SWAP between A and B | 6 |
| | ● If no success: | | |
| 7 | VOTER switch | AUTO | 7 |
| | adjust RPM with power lever | | |
| | Land at nearest suitable airfield | | |
| | If increased climb rate required: | | |
| 8 | Flaps | T/O | 8 |
| 9 | Airspeed..... | 72 KIAS | 9 |
| 10 | Power lever | ADJUST to max. 2300 RPM | 10 |

RPM UNDERSPEED

- | | | | |
|---|-----------------------------------|----------------------|---|
| 1 | Power lever | AS REQUIRED | 1 |
| 2 | VOTER switch | SWAP between A and B | 2 |
| | ● If no success: | | |
| 3 | VOTER switch | AUTO | 3 |
| 4 | Power lever | AS REQUIRED | 4 |
| | Land at nearest suitable airfield | | |

G1000 WARNINGS**ENG TEMP****COOLANT TEMPERATURE HIGH**

- Check "COOL LVL" caution message
 - ❖ → If "COOL LVL" OUT:
 - ❖ → During climb:
 - ⇒ Reduce power 10%
 - ⇒ Increase airspeed 10 KIAS
 - ⇒ If not returning to green range within 60 seconds: reduce power as far as possible and increase airspeed
 - ❖ → During cruise:
 - ⇒ Reduce power
 - ⇒ Increase airspeed, if necessary descend
 - ⇒ Check coolant temperature in green range
 - If not returning to green range:
 - ⇒ land at nearest suitable airfield
 - ❖ If "COOL LVL" ON:
 - ⇒ Reduce power
 - ⇒ Expect loss of coolant fluid
 - ⇒ Be prepared for emergency landing

OIL TEMP**OIL TEMPERATURE HIGH**

- Check oil pressure
 - ❖ → If too low:
 - ⇒ Reduce power
 - ⇒ Be prepared for loss of oil and engine fail; be prepared for emergency landing
 - ❖ If in green range:
 - ⇒ Reduce power
 - ⇒ Increase airspeed

OIL PRES**OIL PRESSURE LOW**

- Reduce power
- Expect loss of oil
- Land at nearest suitable airfield
- Be prepared for engine fail

GBOX TEMP**GEARBOX TEMPERATURE HIGH**

- Reduce power
- Increase airspeed
 - If gearbox temperature still in red range:
 - ⇒ Land at nearest suitable airfield
 - ⇒ Be prepared for engine fail

L/R FUEL TEMP**FUEL TEMPERATURE HIGH**

- Reduce power
- Increase airspeed
- Consider fuel transfer from AUX to MAIN tank
 - If fuel temperature **not returning** to green range:
 - ⇒ Land at nearest suitable airfield

FUEL PRESS**FUEL PRESSURE LOW**

- Check fuel quantity
- Check fuel valve NORMAL
- Switch fuel pumps ON
 - If FUEL PRESS warning remains:
 - ⇒ Fuel valve to EMERGENCY
 - ⇒ Switch fuel pumps OFF
 - If FUEL PRESS warning still remains
 - ⇒ Be prepared for engine fail

ALTN FAIL**ALTERNATOR FAILED****Batteries will last for about 30 minutes**

- Check circuit breakers
- ESSENTIAL BUS: ON
- Switch off unnecessary electrical equipment
- Land at nearest suitable airfield
- Be prepared for engine fail;
be prepared for emergency landing

ALTN AMPS**HIGH CURRENT****Consumption of electrical power is too high**

Possible reason: fault in wiring or equipment

- Switch OFF electrical equipment as necessary and possible to reduce electric load
 - If problem not cleared:
 - Land at nearest suitable airfield

STARTER**STARTER NOT DISENGAGING**

- Power lever IDLE
- Engine master OFF
- Electric master OFF

DOOR OPEN**UNLOCKED DOORS**

- Reduce airspeed
- Check canopy and rear door visually
 - If canopy and/or rear door unlocked:
 - ⇒ Airspeed below 140 KIAS
 - ⇒ Land at nearest suitable airfield

Do not try to lock the rear door in flight

UNINTENTIONAL FLIGHT INTO ICING

Leave icing area, inform ATC

1	Pitot heat	ON	1
2	Cabin heat.....	ON	2
3	Cabin air	DEFROST	3
4	RPM.....	INCREASE, change periodically	4
5	Alternate air	OPEN	5
6	Emergency windows	OPEN as required	6

HIGH CURRENT

Refer to **Emergency Checklist page 8 "ALTN AMPS"**

TOTAL ELECTRIC FAIL

- | | | | |
|---|--|-----------------|---|
| 1 | Circuit breakers..... | CHECK ALL IN | 1 |
| 2 | Essential bus | ON | 2 |
| | ● If no success: | | |
| 3 | Emergency switch | ON | 3 |
| 4 | Flood light, if necessary..... | ON | 4 |
| 5 | Power | SET | 5 |
| | according power lever position and/or engine noise | | |
| 6 | Flaps | VERIFY POSITION | 6 |
- Land at nearest suitable airfield

ELECTRIC FIRE / SMOKE IN FLIGHT

- | | | | |
|---|------------------------|----------------------|---|
| 1 | Emergency switch | ON | 1 |
| 2 | Avionic master | OFF | 2 |
| 3 | Electric master | OFF | 3 |
| 4 | Cabin heat..... | OFF | 4 |
| 5 | Emergency window..... | OPEN as necessary | 5 |
| 6 | Canopy | UNLATCH as necessary | 6 |
- Land immediately

Consider:

EMERGENCY LANDING (ENGINE OFF) (page 2)

FIRE / SMOKE ON GROUND

- | | | | |
|---|--------------------------|------|---|
| 1 | Power lever | IDLE | 1 |
| 2 | Cabin heat..... | OFF | 2 |
| 3 | Fuel valve | OFF | 3 |
| 4 | Fuel transfer pump | OFF | 4 |
| 5 | Engine master..... | OFF | 5 |
| 6 | Fuel pumps..... | OFF | 6 |
| 7 | Electric master | OFF | 7 |
| After standstill and when engine stopped: | | | |
| 8 | Canopy | OPEN | 8 |

Evacuate

FIRE / SMOKE DURING CONTINUED TKOF

- | | | | |
|--|--------------------------|----------------------|---|
| 1 | Cabin heat..... | OFF | 1 |
| If possible climb to safe height and land ASAP | | | |
| When landing assured: | | | |
| 2 | Fuel valve | OFF | 2 |
| 3 | Fuel transfer pump | OFF | 3 |
| 4 | Engine master..... | OFF | 4 |
| 5 | Fuel pumps..... | OFF | 5 |
| 6 | Electric master | OFF | 6 |
| 7 | Emergency window..... | OPEN as necessary | 7 |
| 8 | Canopy | UNLATCH as necessary | 8 |
| 9 | Flaps | T/O or LDG | 9 |

Approach speed KIAS					
Flaps	1000 kg	1080 kg	1160 kg	1216 kg	1280 kg
T/O	70	73	76	77	78
LDG	69	72	74	76	77

LANDING WITH DEFECTIVE MAIN GEAR TIRE

1 ATC INFORMED 1

For landing:

- Land on RWY side with "good" tire
- Keep wing on "good" side low
- Support directional control with brake

LANDING WITH DEFECTIVE BRAKES

Preferably land on grass.

After touchdown (if necessary):

1	Fuel valve	OFF	1
2	Engine master.....	OFF	2
3	Fuel pumps.....	OFF	3
4	Electric master	OFF	4

FUEL TRANSFER PUMP U/S

1	Fuel valve	EMERGENCY	1
2	Fuel pumps.....	OFF	2
3	AUX fuel quantity	CHECK min 1 USG	3
4	MAIN fuel quantity.....	CHECK max 14 USG	4
5	Fuel valve	Reset to NORMAL	5

SUSPICION OF CARBON MONOXIDE

1	Cabin heat.....	OFF	1
2	Ventilation.....	OPEN	2
3	Emergency windows	OPEN	3
4	Airspeed.....	max 117 KIAS	4
5	Canopy	UNLATCH	5

Push up and lock in cooling gap position

G1000 CAUTION LIGHTS

ECU A FAIL	Page 13	Fault in ECU A
ECU B FAIL	Page 13	Fault in ECU B
FUEL LOW	Page 14	Main tank fuel qty low
VOLTS LOW	Page 14	Bus voltage too low
PITOT FAIL	Page 14	Pitot heating system failed
COOL LVL	Page 14	Engine coolant level low
PITOT HT OFF	No procedure	Pitot heating system OFF

Indications outside of green range

RPM high	page 15
OIL PRESSURE high/low	page 15
OIL TEMPERATURE high/ low	page 15
FUEL TEMPERATURE high/low	page 16
COOLANT TEMPERATURE high/low	page 16
GEARBOX temperature high	page 16
ALTERNATOR load yellow range	page 16

Other abnormal situations

Flap failure	page 16
--------------------	---------

ECU A OR B FAIL**ON GROUND**

- | | | | |
|---|-------------------------|--------------|---|
| 1 | Alternate Air | check CLOSED | 1 |
| 2 | Fuel pumps..... | OFF | 2 |
| 3 | VOTER switch..... | check AUTO | 3 |
| 4 | Other ECU caution | check OFF | 4 |

Clearing procedure:

- | | | | |
|---|--------------------|--|---|
| 5 | VOTER switch..... | set to failed ECU | 5 |
| | | Wait 5 seconds | |
| 6 | Voter switch | AUTO | 6 |
| | ● | If ECU caution persists terminate flight preparation | |

ECU A OR B FAIL**DURING FLIGHT**

Remark: in case of ECU fail the system automatically switches to the other ECU

- | | | | |
|---|------------------------|---|---|
| 1 | Alternate Air | OPEN | 1 |
| 2 | Fuel pumps..... | ON | 2 |
| 3 | Circuit breakers | CHECK/RESET if necessary | 3 |
| 4 | VOTER switch..... | check AUTO | 4 |
| | ● | If ECU caution persists: | |
| | ⇒ | Land at nearest suitable airfield | |
| | ● | If additional engine problems are observed: | |
| | ⇒ | Go to Emergency Checklist page 4 | |
| | | ENGINE TROUBLESHOOTING | |

Remark: after landing the clearing procedure for "ECU FAIL ON GROUND" may be used.

**ECU A AND B FAIL
SIMULTANEOUSLY****DURING FLIGHT**

- Go to **Emergency Ckl page 4** ENGINE TROUBLESHOOTING

FUEL LOW

- Fuel transfer pump: ON
- Check fuel quantity
- Avoid uncoordinated flight
 - If light still ON:
 - ⇒ Expect fuel leak
 - ⇒ Fuel valve to EMERGENCY
 - ⇒ Fuel transfer pump OFF
 - ⇒ Be prepared for emergency landing

MAIN TANK FUEL QTY LOW**VOLTS LOW****BUS VOLTAGE TOO LOW**

Remark: possible reason is a fault in the electrical power supply

- ❖ → On ground
 - ⇒ Terminate flight preparation
- ❖ In flight
 - ⇒ Check circuit breakers
 - ⇒ Switch off unnecessary electrical equipment
 - If light still ON:
 - ⇒ Apply "ALTERNATOR FAIL"-emergency procedure (Emergency Checklist page 7)

PITOT FAIL**PITOT HEATING SYSTEM FAILED**

- check pitot heat ON
 - If in icing conditions
 - ⇒ expect loss of airspeed indication
 - ⇒ leave area with icing conditions

COOL LVL**ENGINE COOLANT LEVEL LOW**

- Monitor annunciations and instruments
- Check „Coolant temperature“ procedure, page 15

INDICATIONS OUTSIDE OF GREEN RANGE

RPM high

Yellow range is permitted for up to 5 minutes if required

- Reduce power
- Keep RPM in green range using the power lever
 - If problem not solved
 - ⇒ Go to „RPM overspeed“ procedure,
Emergency Checklist page 5
 - ⇒ Land at nearest suitable airfield

OIL pressure high

- ❖ → On ground during warm up with low oil temperature
 - Reduce power until oil pressure green, continue warm up at reduced power
- ❖ During flight
 - Check oil temperature
 - Check coolant temperature
 - ❖ → If temperatures within green range
 - ⇒ Oil pressure indication may be faulty; watch temperatures
 - ❖ If temperatures outside of green range
 - ⇒ Reduce power;
 - ⇒ Land at nearest suitable airfield, be prepared for engine fail

Oil pressure low

- Refer to **Emergency Checklist page 6**, “OIL PRES”

Oil temperature high

- Refer to **Emergency Checklist page 6**, “OIL TEMP”

Oil temperature low

- Increase power
- Reduce airspeed

Fuel temperature high

- Refer to **Emergency Checklist page 7**, "L/R FUEL TEMP"

FUEL temperature low

- Monitor fuel temperature
 - If fuel temperature decreases to red range (< 25°C):
 - ⇒ Increase power
 - ⇒ Reduce airspeed
 - If not returning to yellow range:
 - ⇒ Land at nearest suitable airfield

Coolant temperature high

- Refer to **Emergency Checklist page 6**, "ENG TEMP"

Coolant temperature low

Remark: During low power descent from high altitude coolant temperature may decrease

- Check "COOL LVL" caution light
 - If ON
 - ⇒ Reduce power
 - ⇒ Expect loss of coolant fluid
 - ⇒ Be prepared for engine failure

Gearbox temperature high

- Refer to **Emergency Checklist page 7**, "GBOX TEMP"

Alternator load yellow range

- Switch off unnecessary electrical equipment
 - If indication still outside of green range:
 - ⇒ Land at nearest suitable airfield

Flap failure

- Check flaps visually, recheck all flap switch positions
- Approach speeds with abnormal flap setting:

	Approach speed KIAS					
Flaps	940 kg	1000 kg	1100 kg	1200 kg	1216 kg	1280 kg + above
T/O	68	70	74	77	77	78
UP	71	73	78	82	82	83

**FMS Initialization – AUX 4 page
Recommended and compulsory settings**

TIME FORMAT	UTC
NAV ANGLE	MAGNETIC
DIS. SPD	NAUTICAL
ALT. VS	FEET
TEMP	CELSIUS
FUEL	GALLONS
POSITION	HDDD°MM.MM'
AIRSPACE ALERTS	As desired
ARRIVAL ALERT	As desired
VOICE	As desired

MFD DATA BAR FIELDS	1 GS
	2 DIS
	3 ETE
	4 TRK
GPS CDI	
SELECTED	AUTO
COM CHANNEL SPACING	25,0 KHZ
NEAREST APT	
RWY SURFACE	As desired
MIN LENGTH	As desired

Compulsory:

ARINC 424 Distance Coding:

A	B	C	D	E
1	2	3	4	5
F	G	H	I	J
6	7	8	9	10
K	L	M	N	O
11	12	13	14	15
P	Q	R	S	T
16	17	18	19	20
U	V	W	X	Y
21	22	23	24	25